



Exploration & Production

GENERAL SPECIFICATION

INSTRUMENTATION

GS INS 172

**Safety Shut-Down Valve
Standard function
- SDV -**

00	11/03	First issue
Rev.	Date	Notes



Contents

1. Scope	3
2. Reference documents.....	3
3. General description of functions	4
3.1 SDV operating description	4
3.2 List of main functions	4
4. Interfaces description	5
4.1 General description.....	5
4.2 Specific description of field interfaces	6
5. Detailed description of functions	6
5.1 Operator's Commands and mode	6
5.2 Status definition	7
6. Tuning parameters and variables	9
7. Representation and animation description (HMI).....	9
7.1 Events and values to be recorded.....	9
7.2 Alarm handling	10
7.3 Control display	10



1. Scope

The purpose of this document is to define the Standard Function for a Shut-Down Valve, operated by the PSS.

When safety and control logic charts require PCS to operate SDV, PCS digital output will be provided to operate a second solenoid valve.

In order to assist in understanding, this document should be read in conjunction with **GS INS 150**, Design Method for System Configuration Standard Functions.

This Standard Function is a fundamental building block, generally linked to the Safety Bar Standard Function.

This Standard Function proposes solenoid valve test facility, as per project requirements.

Partial stroking facility, if required by project specifications, does not affect this Standard Function, contrary to the solenoid valve test, when achieved by means of additional devices mounted inside the control panels.

Another solution, based on smart devices with enhanced diagnostic capabilities, is not described here since depending on the selected devices; however test status and result will be transmitted to PCS for monitoring and recording purposes.

2. Reference documents

The reference documents listed below form an integral part of this General Specification. Unless otherwise stipulated, the applicable version of these documents, including relevant appendices and supplements, is the latest revision published at the EFFECTIVE DATE of the CONTRACT.

Standards

Reference	Title
Not applicable	

Professional Documents

Reference	Title
Not applicable	

Regulations

Reference	Title
Not applicable	

Codes

Reference	Title
Not applicable	

**Other documents**

Reference	Title
Not applicable	

Total General Specifications

Reference	Title
GS INS 137	Design and Supply of ON/OFF Valve Control Panels
GS INS 150	Design Method for System Configuration Standard Functions

3. General description of functions


3.1 SDV operating description

As per project specifications and provided safety trip is no longer active, the Control Room operator may initiate either an Open command or an Open Authorisation command when a local action is still necessary to open the valve.

Likewise Close operator command may also be requested as per project specifications.

3.2 List of main functions

- Handling of field inputs / outputs with status and discrepancy detection
- Interfacing with higher level Standard Function (e.g. Safety Bar)
- Operator's commands
 - Open authorisation or open command (as per project requirements)
 - Inhibit
 - Close command (as per project requirements)
 - Close command when in solenoid valve test mode (as per project requirements)



4.2 Specific description of field interfaces

Corresponding field interfaces are :

- SY (DO) : solenoid valve operating command: **0 = Close**
- SZH (DI) : open limit switch : **1 = Open**
- SZL (DI) : closed limit switch : **1 = Closed**

Option :

- SPSL (DI) : solenoid valve local bypass : **0 = Active**

Special attention has to be paid when the SDV control panel is fitted with 2 solenoid valves, one operated by the PSS and the other by the PCS. Preference is given to handle discrepancy function within the PCS, which requires the hardwiring of the limit switches to the PCS and to transmit the PSS command status to the PCS (communication time will be taken into consideration).

5. Detailed description of functions

5.1 Operator's Commands and mode

5.1.1 Specific description

5.1.1.1 Open Authorisation or Open Command

Open Authorisation or Open command, as per project specifications, will be available to the operator from process control display when :

- Concerned safety trip is not active (relevant safety bar not tripped)

And

- Operating command status = "Closed"

5.1.1.2 Close command

Likewise, Close command may be required. It will be available to the operator from process control display when Operating command status = "Open"

5.1.1.3 Maintenance inhibit

Available when in maintenance access level

When the maintenance inhibit is active :

- Limit switches are no longer considered in internal Open/Closed status handling.
- Discrepancy is no longer active.
- Controlled part (valve body) is red steady if open and closed limit switches have the same status; else the open or closed or operating in progress status will be displayed as defined below.

Maintenance inhibit status is active when maintenance inhibit command is active.

5.1.1.4 Solenoid valve test

This test is designed to be used when the valve is in the open position. The local bypass of the solenoid valve will maintain the valve to its open position, no matter the status of the PSS solenoid command.

The safety function will always override the test function and trip the output to the closed position when necessary.

Specific display will indicate the test has been stopped for safety reasons, and the local operator shall switch back the by-pass to its normal operating mode, in order to allow the valve to move to its safety position.

When the local bypass of the solenoid valve (SPSL) is detected then the test mode is activated. The Close command is available to the operator when the test mode is active and the safety trip is not active.

Upon activation of the Close command by the operator, an adjustable timer (a few seconds) is launched; when elapsed, the Open command is restored and the test completed.

The local operator will then switch back the bypass to its normal position.

The Control Room operator will enter the completed test status for logging purpose as successful if the local operator has observed the solenoid valve being de-energised, else it will be logged as a failed test.

5.2 Status definition

5.2.1 Operating command status :

Operating command status is set to :

- Open when
 - the concerned safety bar not tripped
 - and
 - Open Authorisation or Open command or (Open test command and test mode) are active
- Close upon activation of
 - the associated safety trip
 - or
 - the Close test command and test mode
 - or
 - the Close operator command (as per project specifications)

5.2.2 Solenoid valve Operating command (DO) :

Same as Operating command status

5.2.3 Open / Closed status

5.2.3.1 Open status

HMI open status is active if Open limit switch is active and Closed limit switch is not active

Open status (internal data) is active if :

- (Operating command status = "Open") and (Open limit switch active and Closed limit switch not active)

or

- (Operating command status = "Open") and maintenance inhibit status is active

5.2.3.2 Closed status

HMI closed status is active if Open limit switch is not active and Closed limit switch is active

Closed status (internal) is active if :

- (Operating command status = "Close") and (Open limit switch not active and Closed limit switch active)

or

- (Operating command status = "Close") and maintenance inhibit status is active

5.2.4 Discrepancy status :

It indicates a discrepancy between the operating command and the limit switches status, after a delay time (operation in progress timer).

Discrepancy status is not active when :

- Internal Closed status is active

or

- Operating command status = "Open" and Closed limit switch is active, as long as Closed limit switch has not moved (only when Open Authorisation command applies)

or

- Internal Open status is active (only when Open Authorisation command applies)

or

- Operation in progress status is active

or

- maintenance inhibit status is active

When in test mode and after an operator Close command, discrepancy will no longer be active.

5.2.5 Operation in progress Status :

Active during "operation in progress" timer counts down

"Operation in progress" timer is activated :

- Upon a status change of the Operating command status from open to close
or
- Upon a change of the closed limit switch from active to inactive when operating command status = open authorisation, (only when Open Authorisation command applies)
or
- Upon a status change of the Operating command status from close to open, (only when Open command applies) .

5.2.6 Fault status :

reports a hardware fault relating to an associated I/O cards (field inputs/output).

5.2.7 Operation counter:

Reports the number of changes of the operating command status (from close to open) when not due to solenoid valve test.

The counter reset command will be issued manually by the operator from the HMI (a dedicated pop-up window at maintenance access level).

6. Tuning parameters and variables

PARAMETER	ACCESS LEVEL
Test timer	Maintenance
"Operation in progress" timer pre-set value	Maintenance

7. Representation and animation description (HMI)

7.1 Events and values to be recorded

7.1.1 Events

- Maintenance inhibit command
- Test mode
- Completed test result
- Operating command Status
- Discrepancy Status
- Fault status

7.1.2 Values

- Operation counter


7.2 Alarm handling

Alarm Description	Priority
Discrepancy Status	Level 2
Fault Status	Level 2

7.3 Control display

The hereafter description gives examples of representation. However, they may be amended dependant on the DCS features.

7.3.1.1 SDV (Shutdown Valve) representation



SDV xxxx ← Hidden label

Symbol  is hidden

7.3.1.2 Miscellaneous

SDV xxxx instrument label and Blue Symbol  appears on operator request (soft key)

SDV xxxx instrument label is used as target area for maintenance inhibit command

A "hand" symbol (full yellow) appears near valve when Open Authorisation (or open or Close) commands are available to the operator.

Blue Symbol  is used as target area for test commands and test status keyboard entry

7.3.2 Animation of the symbol (command and controlled parts)

Display description	Display	Symbol	Tagname on safety bar display
Valve closed or Communication or system fault		White White	White
Open command but Valve closed		Fluid White	White
Valve opening in progress		Fluid Fluid flashing	White
Valve open		Fluid Fluid	Blue
Close command but Valve open		White Fluid	Blue
Valve closing in progress		White Fluid flashing	Blue
Valve discrepancy when closing before acknowledgement (*)		White Red flashing	Red flashing
Valve discrepancy when closing after acknowledgement Or (open and closed limit switches have the same status and maintenance inhibit state active) (*)		White Red	Red
Valve discrepancy when opening before acknowledgement (*)		Fluid Red flashing	Red flashing
Valve discrepancy when opening after acknowledgement Or (open and closed limit switches have the same status and maintenance inhibit state active) (*)		Fluid Red	Red



Valve in an undetermined position after a time delay

7.3.3 Animation of the frames

Display description	Display	Frames
Normal status		
Safety trip		External frame : White
Maintenance inhibit		External frame : Yellow
Solenoid valve test mode		External frame : Blue
Fault (and maintenance inhibition)		Internal frame : Red flashing before acknowledgement Red steady after acknowledgement
Communication or system fault		External frame : Magenta

The events which drive these frame displays may not be mutually exclusive. Therefore, the precedence on the display, from most to least important, shall be : magenta, white, blue, yellow