

Repairing Crude Oil, Liquefied Petroleum Gas, and Product Pipelines

API RECOMMENDED PRACTICE 2200
FOURTH EDITION, SEPTEMBER 2010



AMERICAN PETROLEUM INSTITUTE

Repairing Crude Oil, Liquefied Petroleum Gas, and Product Pipelines

Downstream Segment

API RECOMMENDED PRACTICE 2200
FOURTH EDITION, SEPTEMBER 2010



AMERICAN PETROLEUM INSTITUTE

Special Notes

API publications necessarily address problems of a general nature. With respect to particular circumstances, local, state, and federal laws and regulations should be reviewed.

Neither API nor any of API's employees, subcontractors, consultants, committees, or other assignees make any warranty or representation, either express or implied, with respect to the accuracy, completeness, or usefulness of the information contained herein, or assume any liability or responsibility for any use, or the results of such use, of any information or process disclosed in this publication. Neither API nor any of API's employees, subcontractors, consultants, or other assignees represent that use of this publication would not infringe upon privately owned rights.

API publications may be used by anyone desiring to do so. Every effort has been made by the Institute to assure the accuracy and reliability of the data contained in them; however, the Institute makes no representation, warranty, or guarantee in connection with this publication and hereby expressly disclaims any liability or responsibility for loss or damage resulting from its use or for the violation of any authorities having jurisdiction with which this publication may conflict.

API publications are published to facilitate the broad availability of proven, sound engineering and operating practices. These publications are not intended to obviate the need for applying sound engineering judgment regarding when and where these publications should be utilized. The formulation and publication of API publications is not intended in any way to inhibit anyone from using any other practices.

Any manufacturer marking equipment or materials in conformance with the marking requirements of an API standard is solely responsible for complying with all the applicable requirements of that standard. API does not represent, warrant, or guarantee that such products do in fact conform to the applicable API standard.

Classified areas may vary depending on the location, conditions, equipment, and substances involved in any given situation. Users of this Recommended Practice should consult with the appropriate authorities having jurisdiction.

Users of this Recommended Practice should not rely exclusively on the information contained in this document. Sound business, scientific, engineering, and safety judgment should be used in employing the information contained herein.

API is not undertaking to meet the duties of employers, manufacturers, or suppliers to warn and properly train and equip their employees, and others exposed, concerning health and safety risks and precautions, nor undertaking their obligations to comply with authorities having jurisdiction.

Information concerning safety and health risks and proper precautions with respect to particular materials and conditions should be obtained from the employer, the manufacturer or supplier of that material, or the material safety data sheet.

All rights reserved. No part of this work may be reproduced, translated, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission from the publisher. Contact the Publisher, API Publishing Services, 1220 L Street, NW, Washington, DC 20005.

Copyright © 2010 American Petroleum Institute

Foreword

This recommended practice was prepared under the auspices of the API Operations Technical Group (Pipeline). It is intended for use by API member companies and others to develop safe practices for the repair of pipelines in crude oil, liquefied petroleum gas, and product service. The information presented represents a consensus on desirable approaches to repairs.

The use of this recommended practice is entirely voluntary and is intended to apply to repairing of piping used in the transmission of crude petroleum, liquefied petroleum gases, petroleum products and where applicable to other pipeline systems.

This recommended practice represents the combined efforts of many engineers who are responsible for the design, construction and operation of pipelines and the committee appreciatively acknowledges their wholehearted and valuable assistance.

Nothing contained in any API publication is to be construed as granting any right, by implication or otherwise, for the manufacture, sale, or use of any method, apparatus, or product covered by letters patent. Neither should anything contained in the publication be construed as insuring anyone against liability for infringement of letters patent.

Shall: As used in a standard, “shall” denotes a minimum requirement in order to conform to the specification.

Should: As used in a standard, “should” denotes a recommendation or that which is advised but not required in order to conform to the specification.

This document was produced under API standardization procedures that ensure appropriate notification and participation in the developmental process and is designated as an API standard. Questions concerning the interpretation of the content of this publication or comments and questions concerning the procedures under which this publication was developed should be directed in writing to the Director of Standards, American Petroleum Institute, 1220 L Street, NW, Washington, DC 20005. Requests for permission to reproduce or translate all or any part of the material published herein should also be addressed to the director.

Generally, API standards are reviewed and revised, reaffirmed, or withdrawn at least every five years. A one-time extension of up to two years may be added to this review cycle. Status of the publication can be ascertained from the API Standards Department, telephone (202) 682-8000. A catalog of API publications and materials is published annually by API, 1220 L Street, NW, Washington, DC 20005.

Suggested revisions are invited and should be submitted to the Standards Department, API, 1220 L Street, NW, Washington, DC 20005, standards@api.org.

Contents

	Page
1 Scope	1
2 Normative References	1
3 Preliminary Knowledge	2
3.1 Personnel	2
3.2 Safety Procedures	2
4 Pre-departure Practices	2
4.1 General	2
4.2 Preplan Procedures	2
5 Site Hazard Assessment	3
5.1 General	3
5.2 Site Hazard Assessment Procedures	4
5.3 Leak Site Area Assessment Procedures	4
6 Excavation	5
6.1 General	5
6.2 OSHA Construction Standard Checklist	5
7 Repair Practices	6
7.1 General Repair Procedures	6
7.2 Available Repair Methods	8
7.3 Safe Repair Steps	8
8 Post-job Practices	10
9 Special Considerations for Liquefied Petroleum Gas (LPG) or Other Highly Volatile Liquids Pipelines	10
9.1 Significant Characteristics and Their Related Problems	10
9.2 Precautions	11

Repairing Crude Oil, Liquefied Petroleum Gas, and Product Pipelines

1 Scope

This recommended practice (RP) discusses guidelines to safe practices while repairing in-service pipelines for crude oil, liquefied petroleum gas, highly volatile liquids and product service. Although it is recognized that the conditions of a particular job will necessitate an on-the-job approach, the observance of the suggestions in this document should improve the probability that repairs will be completed without accidents or injuries.

2 Normative References

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

API Standard 1104, *Welding of Pipelines and Related Facilities*

API Recommended Practice 1117, *Movement of In-Service Pipelines*

API Standard 1160, *Managing System Integrity of Hazardous Liquid Pipelines*

API Publication 1161, *Guidance Document for the Qualification of Liquid Pipeline Personnel*

API Recommended Practice 1166, *Excavation Monitoring and Observation*

API Recommended Practice 2009, *Safe Welding, Cutting, and Other Hot Work Practices in the Petroleum and Petrochemical Industries*

API Recommended Practice 2201, *Safe Hot Tapping Practices in the Petroleum and Petrochemical Industries*

ASME B31.4 ¹, *Pipeline Transportation Systems for Liquid Hydrocarbons and Other Liquids*

ASME B31G, *Manual for Determining the Remaining Strength of Corroded Pipelines*

ASME B31Q, *Pipeline Personnel Qualification*

ASME PCC-2, *Repair of Pressure Equipment and Piping*

ASME Sec IX, *Boiler and Pressure Vessel Code*

ASNT SNT-TC-1A ², *Personnel Qualification and Certification in Non-Destructive Testing*

DOT Regulations ³, *Title 49 Code of Federal Regulations Part 195: Transportation of Hazardous Liquids by Pipeline*

OSHA Regulations ⁴, *Title 29 Code of Federal Regulations Part 1910 and Part 1926*

PRCI PR-218-9307 ⁵, *Pipeline Repair Manual*

¹ ASME International (formerly American Society of Mechanical Engineers), 3 Park Avenue, New York, New York 10016-5990, www.asme.org.

² American Society for Nondestructive Testing, 1711 Arlingate Lane, P.O. Box 28518, Columbus, Ohio 43228, www.asnt.org.

³ Department of Transportation. The *Code of Federal Regulations* is available from the U.S. Government Printing Office, Washington, D.C. 20402. www.gpoaccess.gov

⁴ U.S. Department of Labor, Occupational Safety and Health Administration, 200 Constitution Avenue, NW, Washington, DC 20210, www.osha.gov.

3 Preliminary Knowledge

3.1 Personnel

Qualified oversight is a prerequisite to the successful implementation of pipeline repair practices. Regulatory requirements for the qualification of pipeline personnel performing repair activities are covered in DOT Regulation 49 *CFR* 195.501 through 195.509 of Subpart G (Operations and Maintenance). Guidance for the development and implementation of Operator Qualification (OQ) programs and procedures are given in ASME B31Q, *Pipeline Personnel Qualification*, and in API 1161, *Guidance Document for the Qualification of Liquid Pipeline Personnel*. Personnel working on pipeline repairs must understand the importance of careful planning to ensure safe and efficient practices and procedures. Employees and contractors should be briefed on-site about specific repairs and safety procedures. Only personnel with the proper training, experience and demonstrated skills should be allowed to perform pipeline repairs.

3.2 Safety Procedures

Repair personnel must have a basic knowledge of safety procedures that includes, but not limited to, lockout and tag out, confined space, worker's right-to-know, personal protective equipment, excavation and trenching, fire prevention and protection, emergency response, atmospheric testing devices, hot work, work permitting, respiratory protection, hydrogen sulfide, hearing conservation, first aid, hazardous substances, fall protection, ergonomics, electrical hazards, and abrasive blasting. Regulations to protect worker safety are covered in OSHA 29 *CFR* 1910 (operations) and 29 *CFR* 1926 (construction).

The company person or designee with overall responsibility for the repair should review previous testing and repair files to determine the presence or absence of asbestos-containing pipe coatings, lead-based paint, or other substances requiring special attention. If coatings are identified to contain hazardous substances, special work practices designed by the company's health and safety department to mitigate employee exposure should be used. Additional handling and disposal requirements may be specified by local, state or federal agencies, consult regulations in your area to determine and develop appropriate handling procedures.

In addition, the company person or designee with overall responsibility for the repair should be knowledgeable about the most recent Department of Transportation Alert Notices and National Transportation Safety Board recommendations related to pipelines as they may pertain to the specific repair situation.

4 Pre-departure Practices

4.1 General

When piping revisions, replacements, or repairs are needed, the goal is to safely and efficiently complete the work. Work shall include in-service and out of service repairs. To ensure the safe and efficient completion of the repair project, the proper preplanning and groundwork must be accomplished before any work is done.

4.2 Preplan Procedures

The preplan should include the following steps.

- a) Consult and comply with all applicable laws and regulations.
- b) Notify "ONE CALL" service, if provided in the area or, if not, contact the owners of the buried facilities directly, giving notice of the work and allowing ample time for other buried facilities to be located and marked. (811 National One Call number.)

⁵ Pipeline Research Council International, Inc., 1401 Wilson Boulevard, Suite 1101, Arlington, Virginia 22209, www.prci.org.

- c) Evaluate reported damage and determine if a Safety-related Condition Report should be filed with the Department of Transportation.
- d) Evaluate reported damage and determine appropriate repair method required to mitigate the condition.
- e) Develop a written work plan that includes the proper repair procedure, drain-down or isolation procedures and appropriate equipment required to complete the repair project safely and efficiently.
- f) Determine pipeline operating characteristics required during the repair project. Determine if pipeline pressure de-rating and/or shut down is required to complete the repair project safely.
- g) Obtain any required permits, including landowner, local government, other regulatory agencies, company general and hot work permits, if required.
- h) Ensure all tools and safety equipment is in good working order.
- i) Brief all line repair personnel on the proper safety procedures and preplan requirements.
- j) Notify personnel at the control center and discuss the line repair plans. Pipeline flow conditions, such as pressure and flow rate at the site of the repair, should be considered prior to the actual initiation of the repair. In service repairs may require reduced operating characteristics and specific flow or no-flow conditions dependent upon specific Operator procedures. Out of service repairs or replacements may require line shut down, isolation and evacuation prior to work initiation. Emergency procedures should also be reviewed with the control center personnel.
- k) Ensure adequate fire protection equipment is available for emergencies and during welding or hot work activities.
- l) Ensure all communications equipment is in good working order and establish a procedure for the control center to monitor the job's progress.
- m) Ensure all communications and other electronic equipment is intrinsically safe or ensure that this equipment will be used a safe distance from potential vapor sources.
- n) Close, lock, and tag the valves connected to the line section to be repaired, if line is required to be isolated and taken out of service during the repair completion.
- o) Open, lock, and tag the circuit breakers on any pumps and motor operated valves that could affect the safety of the job.
- p) Open, lock, and tag the circuit breakers on any rectifier/ground bed installations that could affect the safety of the job.

5 Site Hazard Assessment

5.1 General

A site hazard assessment should be performed prior to commencing any work activity inclusive of piping revision, replacement or repair work, in-service or out of service. Thorough review and assessment of site conditions and project requirements shall provide the basis to organize and complete the repair activity in a safe, controlled, and efficient manner.

5.2 Site Hazard Assessment Procedures

Repair work sites shall include a pre-job hazard assessment prior to initiation of work. The hazard assessment shall include but not be limited to the following.

- a) Specific company work or hot work permitting requirements and review with repair crew personnel.
- b) Consideration of appropriate egress and ingress type and spacing. Excavations greater than 4 ft deep require additional considerations such as ladders, stairways, and ramps located within 25 ft maximum spacing to provide adequate means of ingress and egress.
- c) Gas testing and monitoring requirements. Access or continuous gas monitoring may be required dependant upon the location and type of repair work to be completed. Excavations greater than 4 ft in depth shall require atmospheric testing to confirm oxygen deficiency or presence of hazardous atmosphere. Proper mitigation of all hazards identified shall be completed prior to allowing entrance to the excavation.
- d) Excavation requirements, inclusive of sheeting and shoring design implementation requirements. Excavations less than 5 ft require inspection and documentation by a competent person. Appropriate sloping may be required as a result of the competent person evaluation. Excavations greater than or equal to 5 ft require sloping, sheeting or shoring protection to mitigate the potential of trench wall collapse. The appropriate sloping, sheeting or shoring technique utilized shall be determined based upon soil conditions, as assessed by a competent person. Refer to OSHA Safety and Health Regulations for Construction, 29 *CFR* Part 1926.652, for specific excavation safety regulatory requirements.
- e) Confined space analysis, if required. Appropriate personnel safety control, monitoring and retrieval systems shall be available prior to initiating any work within a confined space.
- f) Equipment status and Energy Control requirements, i.e. Lockout/Tagout (LOTO) or specific product isolation and control information and requirements should be reviewed and documented prior to work initiation. A project may require a system walk through and review to ensure system status and control is adequate for work intended.
- g) Personal protective equipment (PPE) requirements to complete the job safely.
- h) Miscellaneous safety requirements such as fire watch, ventilation, bonding/grounding, signage, and barricades shall be considered.

5.3 Leak Site Area Assessment Procedures

If a repair is required because of damage that has resulted in a petroleum product release or the petroleum product has spilled during the repair, additional site specific hazard assessments must be performed. This hazard assessment should result in a worksite safety plan. A hazard zone should be established by determining the amount of hydrocarbon vapors in the area. Information that is contained in the Material Safety Data Sheet must be consulted to determine the material's volatile and toxic characteristics. The initial monitoring of the area should be completed with full protective equipment as recommended by the Material Safety Data Sheet.

A leak site area assessment should include the following additional steps.

- a) The area's flammability level should be checked with a combustible gas indicator prior to entering site. Areas above 10 % of the lower explosive limit (LEL) should be declared hazardous and the personal exposure limit (PEL) determined. Access should be restricted. These areas should be further evaluated for proper PPE, ingress/egress and work requirements.

- b) Toxicity testing should be made with direct reading instruments that may include colorimetric tubes. This toxicity testing will determine the level of protective equipment required for the area.
- c) If a confined space is involved, such as a trench, always check for safe oxygen level.
- d) Personnel and equipment should not be permitted in the area until the hazard area has been defined and mitigation or entry plan developed.
- e) Restrict equipment and other ignition sources from the flammable hazard zone.
- f) All personnel who enter the toxic hazard zone must be equipped with proper protective gear (PPE).
- g) All personnel leaving the toxic hazard zone shall be subjected to proper decontamination protocols prior to re-emerging into a toxic hazard free clean zone.
- h) If the hazard area extends into public areas, local authorities should be used to warn the public and to restrict access to the area. If public access is possible, suitable warnings should be posted.
- i) The leak site should be barricaded and marked to prevent the possibility of accidents and injuries. Consideration should be given to appropriate additional security measures to prevent spectators from entering the hazard area at any time.
- j) Some leaks, according to their severity or hazards, may require compliance with the Occupational Safety and Health Administration's (OSHA) Hazwoper Standard (29 *CFR* Part 1910.120).

6 Excavation

6.1 General

All excavations that personnel must enter shall conform to OSHA Construction Standard (29 *CFR*, Part 1926, Subpart P). All excavations must be assessed by a competent person to determine appropriate level of protection required for safe entry. The OSHA Construction Standard regulates the use of support systems, sloping and benching, and other systems of protection against excavation cave-ins. In addition, it regulates the means of access to and egress from excavations and employee exposure to vehicular traffic, falling loads, hazardous atmospheres, water accumulations, and unsafe structures in and adjacent to excavations. Excavations are defined in the Construction Standard to include trenches.

6.2 OSHA Construction Standard Checklist

To ensure that existing and predictable hazards are identified at the worksite, the following checklist is provided as an outline of the OSHA Construction Standard.

- a) Have "ONE CALL" notifications been made or other means used to determine what underground utilities are in the area? (811 National One Call Phone Number.)
- b) Is the excavation more than 4 feet in depth and evaluated for hazardous atmosphere (flammability, oxygen content, toxicity, H₂S, Carbon Monoxide)?
- c) Has excavation been evaluated for adequate means of ingress and egress?
- d) Has a stairway, ladder, ramp, or other safe means of ingress/egress been provided and properly spaced?
- e) Has a trained and qualified competent person (as defined by the OSHA standard) been designated?

- f) Has the soil been categorized (stable rock, Type A, Type B, or Type C)?
- g) Does the excavation require sloping, shoring, or shielding?
- h) Is the excavation greater than or equal to 5 ft in depth and have sheeting and shoring requirements been evaluated?
- i) Is the excavation more than 20 ft in depth? (If yes, a protection system designed by a professional engineer will be required.)
- j) Is the excavation a permit-required confined space?
- k) If excavation protection is required, which system will be used?
- l) Have Manufacturer's Engineering Tabulated Data Sheets, specification of the protective device load rating, for the shoring or shielding system considered been reviewed and evaluated? Has appropriate shoring protection system been selected for the proposed site conditions? Protection system engineering data should remain available for reference on site.
- m) Has a safe excavation protective system installation and removal procedure been developed to protect the employees who will be performing these tasks?
- n) Has adequate protection been provided to protect employees from materials falling or rolling from the excavation face or from the surface in the vicinity of the excavation?
- o) Is the spoils pile a minimum of 2 ft (24 in.) from the edge of the excavation?
- p) Has adequate protection been provided for water accumulation in the excavation?
- q) Is emergency rescue equipment available at the jobsite? (If confined space has the local emergency response or rescue contractor been notified?)
- r) Has stability of adjacent structures been considered as a result of the excavation?
- s) Are daily inspections of the excavations being made?

This checklist is designed only as a reminder; the details of the OSHA Construction Standard can be found in Subpart P of 29 *CFR* Part 1926.

7 Repair Practices

7.1 General Repair Procedures

7.1.1 If damage or imperfections are discovered on a pipeline, a decision to repair or not to repair will be made. When practical, an injurious pipe defect may be completely removed from the pipeline by replacing the portion of the pipe containing the defect. The welding procedures and welders performing the repair shall be qualified in accordance to API 1104 or ASME Section IX, dependent upon mainline or facility piping. If the repair is to be performed on in-service piping, the procedures and welders must be qualified in accordance to API 1104 Appendix B. Consideration should be given to assuring the replacement section of pipe meets the minimum design requirements of the pipeline and has been hydrostatically tested prior to placing in service. The length of the replacement pipe should be a minimum of one half the diameter of the pipe but no shorter than 3 in. No new weld shall be installed closer than 3 in. to an existing weld. If pipe replacement is not practical, other methods of permanent repairs are covered in ASME B31.4, API 1160, PRCI's *Pipeline Repair Manual*, and ASME PCC-2. If repairs are warranted, but

not immediately practical, temporary repairs may be considered. Defect evaluation shall be conducted using ASME B31G or other acceptable engineering analysis methodology.

7.1.2 Temporary repairs (that is, clamps or mechanically-applied full encirclement sleeves) may be necessitated for operating purposes. The temporary repairs shall be made in a safe manner and in accordance with the manufacturer's instructions. As soon as practical, the temporary repairs shall be replaced in a permanent manner or welded permanently, if so designed. De-rating (lowering) the line's maximum operating pressure may be required until permanent repairs are made, depending on the conditions and the design of the temporary repair. For particularly sensitive or critical locations, the operator may consider leaving the repair excavation site open and maintain personnel onsite to monitor the temporary repair while it is in operation, until the permanent repair can be completed. ASME B31.4 specifically outlines recommendations that address these issues.

7.1.3 When pipe replacement or the clamping procedure is not feasible or sufficient to permit returning the line to service, hot tapping the line to provide a means of inserting plugs (stopples) to isolate the defective line section may effect a safe repair (see API 2201). A bypass may be installed around the defect/release to permit continued operations while the defective section is drained and repaired. Consideration should be given to factors such as product characteristics, pipe condition, temperatures, and required differential pressures to ensure that the proper type of plug is used and that its holding capacity can adequately resist the pressure to be encountered. Only OQ qualified personnel trained for this operation should install and operate tapping and plugging equipment, or qualified representatives of the manufacturer should be available to assist.

7.1.4 If it is feasible to remove the pipeline from service, repairs may be accomplished by hot tapping the line and installing a connection through which the pipeline's contents can be drained, vented, or flared, as in the case of a highly volatile liquids (HVL) line, to a place that is safe for disposal. Alternately, an inert gas such as nitrogen may be used to safely displace (purge) the contents of the pipeline system to a downstream location, for the purpose of repair or replacement. The potential energy of compressed gas, such as nitrogen, presents special concerns and handling.

7.1.5 After draining or purging has been completed and pressure has been reduced to atmospheric pressure, the line may be cold cut and the defective section replaced. Disposal of contaminated soil and other material should be handled or disposed of in accordance with federal, state, and local requirements. When a portion of the line is to be removed, there are several methods of safely preparing the line for welding the new section into place. These methods include, but are not limited to, inert gas purging, mud plugging, ice plugging, and mechanical plugging. Each method has advantages and disadvantages based on the repair conditions. See API 2201 for more details.

7.1.6 In all cases a written work plan should be generated and communicated outlining the process, procedures and responsible parties required to complete the work in a safe manner. The plan should include, but not be limited to:

- a) Job Hazard Analysis;
- b) review of hazards and plan with all individuals involved in the drain or purge;
- c) notification of local authorities, hazmat agencies and property owners who could be involved with noise or operational complaints/concerns;
- d) maximum flow rate of the fluid being displaced;
- e) maximum pressure requirements at the nitrogen injection or drain site;
- f) maximum operating pressure of the pipeline system to be displaced;
- g) nitrogen injection temperature and system temperature requirements;
- h) inert gas handling and use precautions;
- i) overpressure protection.

7.2 Available Repair Methods

Refer to ASME B31.4 and PRCI *Pipeline Repair Manual* for specific repair method installation guidelines and details. The appropriate repair method selected shall be based upon the type, dimensions and severity of defect investigated and results of proper engineering analysis and evaluation. Specific company specifications and procedures should be consulted to determine applicability of repair method selected.

- a) Mechanically installed full-encirclement sleeve—Installed on a temporary or permanent basis to contain a leaking or near leaking condition. In some cases, the sleeve may be welded for permanent repair similar to requirements of Type B sleeves or by encapsulating with a domed fitting. Consult ASME B31.4, manufacturer's guidelines and PRCI manual for limitations of use.
- b) Type A Steel Sleeve—Nonpressure containing steel sleeve with non shrinkable epoxy filling any voids.
- c) Type B Steel Sleeve—Pressure containing sleeve with welded ends and nonshrinkable epoxy filling any voids. Single sleeve or sleeve on sleeve arrangements. Considerations should be given to length of sleeve to install and fit up required. Adjacent sleeves shall adhere to minimum one half pipe diameter or 4 in. from a girth weld, whichever is greater, weld spacing to avoid notching effect. The internal design pressure of the sleeve material shall meet or exceed that of the carrier pipe.
- d) Composite Sleeve—Non-leaking defects with a depth <80 % and other types of anomalies approved. A written procedure and trained personnel must be used for installation.
 - Cold applied—fiberglass resin reinforced coil system with non shrinkable epoxy filling voids and epoxy adhesive system.
 - Wet applied—Kevlar or other engineered fabric impregnated with epoxy adhesive. Engineered calculations are required to determine appropriate number of repair wraps to mitigate the defect identified.
 - Epoxy Filled Shell—Steel shell with a standoff distance from the pipe, with welded sides, non-shrinkable epoxy filler seals at the ends and epoxy injected into the interstitial space.
- e) Deposited Weld Metal (Weld metal overlay) (Puddle Welding)—Temper bead deposition technique may be well suited to complete this type of repair, limiting the potential for high HAZ hardness and hydrogen cracking.
- f) Grinding—Follow ASME B31.4 recommended limitations.
- g) Hot Tapping—This technique should only be considered if the defect can be completely removed by the branch size selected of the hot tapping process and proper evaluation of the fitting fillet weld area conducted ensures that the pipe is free of additional defects and maintains adequate wall thickness to complete the planned welding safely.
- h) Patches—Neither patches nor half soles shall be installed on pipelines. Refer to ASME B 31.4 – 2006

Use and installation of repair methods listed above shall adhere to the appropriate paragraphs of ASME B31.4 and PRCI manuals. Selection and use of a repair method should be the result of careful engineering review, analysis, and evaluation of the defect.

7.3 Safe Repair Steps

To ensure that the pipeline is repaired in a safe manner, the following steps and precautions should be taken.

- a) Repair techniques used shall be in accordance with ASME B31.4.

- b) OQ qualified personnel requirements must be adhered to.
- c) Repairs shall be performed under qualified supervision by trained personnel aware of and familiar with the hazards to personnel, the public, and the environment.
- d) Calculations should be performed to determine the amount of pipe movement that is permissible during the proposed repair. These calculations should consider the pipe metallurgy so that proper pipeline support can be provided during the repair work. (Consult API 1117.)
- e) Requirements for supporting pipe both during and after construction should be determined to ensure that the pipe is not overstressed and to maximize safety.
- f) All welding and testing shall be in accordance with ASME B31.4, ASNT SNT-TC-1A and API 1104. All welds shall be made by qualified welders using qualified procedures. Prior to welding pipe replacements, the internal surface of the pipe must be inspected and documented.
- g) When the carrier pipe is being welded, the wall thickness shall be confirmed through the use of ultrasonic measurement equipment or other suitable devices, to determine presence of adequate wall thickness and lack of laminations to confirm safe to weld.
- h) All rectifiers in the area should be turned off, locked, and tagged. This includes the company rectifiers, as well as foreign pipeline rectifiers whose line is bonded to the line under repair or whose line passes in proximity to the line.
- i) Because of the possibility of electrical currents on the pipeline, an electrical bond should be made across all proposed points of separation before the line is cut or a flange joint is separated. If replacement pipe is required, the pipe joint or joints should also be bonded. The bond should not be removed until repairs have been completed. Where stray currents are present, it may be necessary to install a ground grid.
- j) Line cuts, when required, should be made with mechanical cutters. Removed defect area should be protected from further damage, well marked, and stored in a controlled manner should additional third party defect testing and analysis be required.
- k) Torch cutting may be considered, after the contents of the line have been positively confirmed, properly evacuated and an effective isolation barrier established to ensure that no hazardous vapors can enter the cutting area.
- l) If welding is to be performed, all oils, products, and saturated earth should be removed both from within and around the excavation. It may be necessary to install a vapor barrier and spread uncontaminated dirt/sand around and on the bottom of the excavation.
- m) The excavation and its surrounding area should be tested and continuously monitored with a combustible gas indicator or oxygen monitor, or both, to determine that the atmosphere is safe for such work.
- n) Where vapor seals or plugs are used to prevent the escape of vapor from a pipeline, some positive method of venting or monitoring should be used to ensure against a pressure buildup in the line while hot work is in progress. Vents shall be confirmed open and periodically checked to confirm un-obstructed prior to and during hot work activities.
- o) If oil, product, or vapors enter the excavation after hot work is started, the work should be halted immediately, and the oil, product, or vapor removed or mitigation process identified and implemented. The atmosphere should be retested prior to continuing the hot work.
- p) Upon completion of the repair, necessary inspections, tests, and operating checks should be made before placing the line in service.

8 Post-job Practices

After a repair job is completed, there are post-job considerations to ensure the effectiveness of the preplanning and the on-the-job plan execution is not compromised by improper work completion practices. The following checklist provides some of those considerations.

- a) After all repair work is completed and inspected, personnel at the control center should be notified that the line is ready for service.
- b) All valves and circuit breakers should be unlocked and untagged and operated in accordance with company procedures and control center instructions. All affected personnel should be notified.
- c) After startup, the line repair should be visually monitored for leaks until normal operation is restored.
- d) All rectifiers should be untagged and turned on.
- e) The pipe should be properly supported and coated per company guidelines.
- f) The backfilling operation should be done in a careful manner so as not to damage any existing or new pipe coating and to affect good compaction. Adequate compaction techniques should be utilized to limit settling.
- g) Following the completion of a permanent repair, the site should be restored.
- h) Contaminated soil and other materials should be handled or disposed of in accordance with local, state, and federal regulations.
- i) All documentation should be completed, including but not limited to, the type of repair made and the materials used, location of the repair, hydrostatic test information and welding records, the weld locations, any evidence of internal or external corrosion, NDT records.
- j) All DOT, 49 *CFR* Part 195, and any other federal, state, or local reporting requirements should be completed.

9 Special Considerations for Liquefied Petroleum Gas (LPG) or Other Highly Volatile Liquids Pipelines

9.1 Significant Characteristics and Their Related Problems

The preceding procedures are generally applicable to the repair of pipelines handling liquefied petroleum gas (LPG) or other highly volatile liquids, but personnel assigned to repair crews for pipelines should be well informed about the characteristics of the special materials that they may handle and the special problems that they may encounter if leaks occur. The most significant characteristics and their related problems are as follows.

- a) The boiling points of LPG materials are well below usual ambient temperatures; therefore, any liquid released as a result of a leak usually converts rapidly to vapor. Further, releases of such a liquid or vapor can create an explosive atmosphere over a large area.
- b) Since the vapors of LPG materials (like those of gasoline) are heavier than air and thus tend to remain close to the ground, the precautions outlined in the preceding sections are especially applicable to the potential hazards associated with LPG leaks.
- c) Vaporization of leaking LPG may freeze the surrounding ground and pipeline appurtenances, and the danger exists that escaping gas could cause frostbite if it contacts exposed parts of the body.

- d) The refrigerating effect of LPG on the ground can also cause difficulties in excavation.
- e) Since LPGs have substantially greater volatility than crude oil or gasoline, additional precautions may be required when leaks occur.
- f) Evacuation and isolation of LPG pipelines may require additional safety considerations. Vapor dispersal and accumulation during venting and drain down activities may limit effectiveness of conventional product evacuation techniques. Consideration should be given to utilizing portable flare units, if available and permitted by local or state regulations, to mitigate vapor accumulation. In situ flaring coupled with conventional drain down procedures may be effective tools in handling the unique LPG characteristics.

9.2 Precautions

Following the detection of a leak, the following precautions (not necessarily in the order shown) should be taken:

- a) Eliminate all nearby ignition sources (especially those downwind of the leak) and evacuate adjacent areas that may be in danger.
- b) Determine with a combustible gas indicator the extent of any explosive atmosphere in the area.
- c) If conditions warrant, contact appropriate public officials for assistance in isolating the area, controlling traffic, evacuating nearby residential areas, and controlling spectators.
- d) Review the characteristics of the specific LPG to determine the lower, upper explosive limits and personal exposure limits to determine appropriate level of PPE required to access and work in the release or work site.



AMERICAN PETROLEUM INSTITUTE

2010 PUBLICATIONS ORDER FORM

Effective January 1, 2010. API Members receive a 30% discount where applicable. The member discount does not apply to purchases made for the purpose of resale or for incorporation into commercial products, training courses, workshops, or other commercial enterprises.

Ordering Information Online: www.api.org/pubs
Phone: **1-800-854-7179** (Toll-free in the U.S. and Canada) | **(+1) 303-397-7956** (Local and International)
Fax: **(+1) 303-397-2740**

Date: _____

☐ **API Member** (Check if Yes)**Invoice To** ☐ Check here if same as "Ship To")

Name: _____

Title: _____

Company: _____

Department: _____

Address: _____

City: _____

State/Province: _____

Zip/Postal Code: _____

Country: _____

Telephone: _____

Fax: _____

Email: _____

Ship To (UPS will not deliver to a P.O. Box)

Name: _____

Title: _____

Company: _____

Department: _____

Address: _____

City: _____

State/Province: _____

Zip/Postal Code: _____

Country: _____

Telephone: _____

Fax: _____

Email: _____

Quantity	Title	SO ★	Unit Price	Total
	Std 1104, Welding of Pipelines and Related Facilities		\$286.00	
	RP 1117, Movement in In-Service Pipelines		\$128.00	
	Std 1160, Managing System Integrity for Hazardous Liquid Pipelines		\$186.00	
	Publ 1161, Guidance Document for the Qualification of Liquid Pipeline Personnel		\$227.00	
	RP 1166, Excavation Monitoring and Observation		\$102.00	
	RP 2009, Safe Welding, Cutting and Hot Work Practices in the Petroleum and Petrochemical Industries		\$76.00	
	Publ 2201, Safe Hot Tapping Practices in the Petroleum and Petrochemical Industries		\$83.00	

☐ Payment Enclosed ☐ P.O. No. (Enclose Copy) _____☐ Charge My IHS Account No. _____☐ VISA☐ MasterCard☐ American Express☐ Diners Club☐ Discover

Credit Card No.: _____

Print Name (As It Appears on Card): _____

Expiration Date: _____

Signature: _____

Subtotal**Applicable Sales Tax** (see below)**Rush Shipping Fee** (see below)**Shipping and Handling** (see below)**Total** (in U.S. Dollars)

★ To be placed on Standing Order for future editions of this publication, place a check mark in the SO column and sign here:

Pricing and availability subject to change without notice.

Mail Orders – Payment by check or money order in U.S. dollars is required except for established accounts. State and local taxes, \$10 processing fee, and 5% shipping must be added. Send mail orders to: **API Publications, IHS, 15 Inverness Way East, c/o Retail Sales, Englewood, CO 80112-5776, USA.**

Purchase Orders – Purchase orders are accepted from established accounts. Invoice will include actual freight cost, a \$10 processing fee, plus state and local taxes.

Telephone Orders – If ordering by telephone, a \$10 processing fee and actual freight costs will be added to the order.

Sales Tax – All U.S. purchases must include applicable state and local sales tax. Customers claiming tax-exempt status must provide IHS with a copy of their exemption certificate.

Shipping (U.S. Orders) – Orders shipped within the U.S. are sent via traceable means. Most orders are shipped the same day. Subscription updates are sent by First-Class Mail. Other options, including next-day service, air service, and fax transmission are available at additional cost. Call 1-800-854-7179 for more information.

Shipping (International Orders) – Standard international shipping is by air express courier service. Subscription updates are sent by World Mail. Normal delivery is 3-4 days from shipping date.

Rush Shipping Fee – Next Day Delivery orders charge is \$20 in addition to the carrier charges. Next Day Delivery orders must be placed by 2:00 p.m. MST to ensure overnight delivery.

Returns – All returns must be pre-approved by calling the IHS Customer Service Department at 1-800-624-3974 for information and assistance. There may be a 15% restocking fee. Special order items, electronic documents, and age-dated materials are non-returnable.

THERE'S MORE WHERE THIS CAME FROM.

API Monogram® Licensing Program

Sales: (+1) 713-964-2662
Service: (+1) 202-962-4791
Fax: (+1) 202-682-8070
Email: certification@api.org
Web: www.api.org/monogram

API Quality Registrar (APIQR®)

- ISO 9001
- ISO/TS 29001
- ISO 14001
- OHSAS 18001
- API Spec Q1®
- API QualityPlus®
- Dual Registration

Sales: (+1) 713-964-2662
Service: (+1) 202-962-4791
Fax: (+1) 202-682-8070
Email: certification@api.org
Web: www.api.org/apiqr

API Individual Certification Programs (ICP®)

Sales: (+1) 713-964-2662
Service: (+1) 202-682-8064
Fax: (+1) 202-682-8348
Email: icp@api.org
Web: www.api.org/icp

API Engine Oil Licensing and Certification System (EOLCS)

Sales: (+1) 713-964-2662
Service: (+1) 202-682-8516
Fax: (+1) 202-962-4739
Email: eolcs@api.org
Web: www.api.org/eolcs

API Training Provider Certification Program (API TPCP™)

Sales: (+1) 713-964-2662
Service: (+1) 202-682-8075
Fax: (+1) 202-682-8070
Email: tpcp@api.org
Web: www.api.org/tpcp

API Perforator Design Registration Program

Sales: (+1) 713-964-2662
Service: (+1) 202-682-8490
Fax: (+1) 202-682-8070
Email: perfdesign@api.org
Web: www.api.org/perforators

API Credit Exchange (ACE™)

Service: (+1) 202-682-8192
Fax: (+1) 202-682-8070
Email: exchange@api.org
Web: www.api.org/ace

API Diesel Exhaust Fluid Certification Program

Phone: (+1) 202-682-8516
Fax: (+1) 202-962-4739
Email: info@apidef.org
Web: www.apidef.org

API WorkSafe™

Sales: (+1) 713-964-2662
Service: (+1) 202-682-8469
Fax: (+1) 202-682-8348
Email: apiworksafe@api.org
Web: www.api.org/worksafe

API-U

Phone: (+1) 202-682-8053
Fax: (+1) 202-682-8070
Email: training@api.org
Web: www.api-u.org

API Data™

Phone: (+1) 202-682-8499
Fax: (+1) 202-962-4730
Email: apidata@api.org
Web: www.APIDataNow.org

API Publications

Online: www.api.org/pubs
Phone: 1-800-854-7179
(Toll-free: U.S./Canada)
(+1) 303-397-7956
(Local/International)
Fax: (+1) 303-397-2740

API Standards

Phone: (+1) 202-682-8148
Fax: (+1) 202-962-4797
Email: standards.org
Web: www.api.org/standards

Request a Quotation:
www.api.org/quote



AMERICAN PETROLEUM INSTITUTE



AMERICAN PETROLEUM INSTITUTE

1220 L Street, NW
Washington, DC 20005-4070
USA

202-682-8000

Additional copies are available online at www.api.org/pubs

Phone Orders: 1-800-854-7179 (Toll-free in the U.S. and Canada)
303-397-7956 (Local and International)
Fax Orders: 303-397-2740

Information about API publications, programs and services is available
on the web at www.api.org.

Product No. D220004